Flow Mediated Dilation (FMD)

Dr. Widlansky / Cardiovascular Academic Initiative (CAI)'s Protocol

Medical College of Wisconsin

What is FMD?

- A non-invasive measurement of endothelial function using ultrasound
- FMD is endothelium dependent nitric oxide mediated dilation of the arteries in response to an imposed increase in blood flow & shear stress
- FMD
 - Inflation using a cuff
 - 3 minutes of images post inflation
 - Baseline and hyperemic flow measured
 - Can be done Brachial (upper arm) or Femoral (upper thigh)




- Cuff for inflation
 - Hokanson SC10
 - Hokanson SC5
 - Cuff examples
- Aneroid sphygmomanometer
 - Example
- Measuring tape
- Skin marker if desired
- Bedside table or flat height adjustable surface for patient's arm
- Towels/sheets/washcloths for support of arm



FMD Protocol Basics

- Below cubital fossa protocol
- 5-minute cuff inflation
- 10 second clips (not continuous capture)
 - Baseline(s)
 - RH1
 - RH2
 - RH3



Brachial FMD Protocol

Step by Step

- Patient supine in bed
 - Try to limit to one pillow if possible
 - One arm out on a table supported by towels
 - Patient to be resting for ~10 minutes
- Take three blood pressure measurements
 - Preferably on the opposite arm FMD will be performed
- Place cuff snug on patient's arm just below elbow
- Locate a clean open spot on the brachial artery
- Take a baseline flow image/calculation
- Take 3-5 baseline (BSL) clips
- 5-minute cuff inflation
 - 200mmHg
- Take hyperemic flow image/calculation
- Reactive hyperemia (RH) clips at 1-, 2-, and 3minutes cuff deflation

Nitro-Mediated Dilation (NMD)

Step by Step

Always done on brachial artery, and at last FMD of visit Patient in same position as for brachial FMD

- Locate a clean open spot on the brachial artery
- Take a baseline flow image/calculation
- Take at least 3 baseline (BSL) clips
- Have RN give NTG and note time on ultrasound screen
- Reactive hyperemia (RH) clips at 2-, 3- 4- and 5-minutes post NTG administration

NTG Contraindications:

- 1. Systolic Blood Pressure too low (less than 110mmHg)
- 2. Previous adverse reaction to nitroglycerin (headaches, fainting etc.)
- 3. Used Viagra, Levitra, or Cialis within the past 7 days
- 4. History or migraine or chronic headaches
- 5. Current headache at time of visit



Femoral FMD Protocol

Step by Step

- Patient in Bed (head of bed elevated)
 - In a semi reclined sitting position
 - Can use a pillow under leg (under the knee) to help position
 - Leg slightly bent and knee and flexed outward, the PT's other leg can be covered by a blanket
 - Patient to be resting for ~10 minutes
- Take three blood pressure measurements
- Place cuff snug on patient's leg just ABOVE the knee
- Locate a clean open spot on the femoral artery
- Take a baseline flow image/calculation
- Take 3-5 Baseline (BSL) clips
- 5-minute cuff inflation
 - 200mmHg
- Take hyperemic flow image/calculation
- Reactive hyperemia (RH) clips at 1-, 2-, and 3-minutes cuff deflation


Control Conditions

Most Common


- 8 hour fast from food/drink
- Withhold morning medications (vasoactive)
- Abstain from smoking for at least 6 hours
- No changes in vasoactive medications for past 6 weeks
- If multiple FMDs done try to stick to same time of day

Other Important Considerations


- No vigorous physical activity for 24 hours
- FMD should be performed in a quiet, temperature-controlled room (72-74 degrees if possible)
- FMD should be performed by the same trained operator, when possible, for multiple/follow up FMDs on same subject
- Premenopausal women should be assessed in a standardized part of their menstrual cycle if possible
- Use the same arm for repeat FMD measurements where possible



Analyzable Image Example




Analyzable Image Example



This is an example of a scan that is still workable but not ideal

Analyzable Image Example




If we were able to play this clip, we would see lots of movement as well

Unanalyzable Image Example


Documentation


During Scan




Landmarks can also be marked on screen if that is helpful to prevent drifting

Flow Images







Hyperemic

Documentation

Before / After Scan

- Confirm fasting
- Confirm medication changes
- Time of FMD is time cuff inflation began
- Location of measurement is L/R arm
- Notes about location can include:
 - Angle
 - Pressure
 - Position of patient's arm

Subject Study ID #:	
Date (MM/DD/YY): / /	
Visit # (if applicable):	
Patient fasted food/drink for 8 hours?	YES / NO
Patient refrained from smoking for 6 hours?	YES / NO
Patient withheld any vasoactive medications?	YES / NO
Any changes in medication since last visit?	YES / NO
Performed by (initials): Room Temperature: Celsius Time of FMD:: _ AM/PM Location of measurement: Inches from AC: Additional notes abo	ut location:
FMD BP/HR	
SBP 1: SBP 2: SBP 3:	:AM/PM
DBP 1: DBP 2: DBP 3:	:: AM/PM
HR 1: HR2: HR3:	:AM/PM

Analyzing an FMD

(brief overview)





Program: Brachial Analyzer


Find a clean open location






Note landmarks

Keep consistent spot through entire FMD





Flow Calculations

